

## Pinstripe Kit Installation Instructions

1. Clean thoroughly general area of vehicle where pinstripe is to be applied. 91% Isopropyl Alcohol is commonly recommended by manufacturer for the removing of both dirt, waxes, and airborne/road grease. (available at Walmart, Target, etc.) Use clean virgin towels or cloths to insure area is not contaminated.
2. Use small pieces of tape to set accurate gaps from selected feature line, to help insure accuracy of pinstripe placement.
3. Lay pinstripe by first removing a panel length of paper backing. Press after applying. Continue for vehicle. Not recommended to apply on hot surfaced vehicles. Stripe in the shaded area.
4. After side is complete, remove clear carrier, carefully by pulling it over stripe area, not upwards or downwards, so that carrier does not cause vinyl pinstripes to move or squiggle.
5. After clear carrier is removed, press down vinyl pinstripes with fingers to insure proper contact and bonding and adhesion.
6. Trim vinyl back from doors about 1/8". We recommend using a curved blade; these keep knife blade from cutting or scoring paint.
7. Trim-in logos and name-decals at desired areas. Install fancy front arrows or fashion a traditional point bringing bottom stripe up to top stripe.
8. Vehicle can be washed anytime afterwards HOWEVER, if a power wash is used, we strongly recommend wand sprayer head is kept minimum 24" away from vehicle. Power washers used up-close can damage stripes.

